

# Irrigation Line Cleaning and Disinfecting Program



## Directions

**Step 1:** Remove mineral buildup in irrigation lines with GreenClean Acid Cleaner at 1:100 and hold for 1–2 hours then flush with fresh water.

**Step 2:** To remove inner working layer of biofilm inject SaniDate 5.0 at 1:100 and hold for a minimum of 3 hours. Optional hold time is 8–12 hours. Flush with fresh water.

**Pro Tip:** When flushing system do it in a manner that does not force dead biomass through small/micro emitters.

NOTE: This program should only be carried out when greenhouses are empty and no crops are present.



**SaniDate® 5.0**  
**GreenClean®**  
ACID CLEANER

1.888.273.3088 | [biosafesystems.com](http://biosafesystems.com)

SaniDate® and GreenClean® are registered trademarks of BioSafe Systems, LLC. Always read and follow label directions.

©2018 Copyright BioSafe Systems LLC. All rights reserved. HT18-05